craft express

Mug Press for 11 - 15oz Mugs

craft express





USER MANUAL





SAFETY INSTRUCTIONS

To avoid injury or death caused by electric shock, please read all the instructions before using the machine.

- 1. Keep the machine unplugged when moving it;
- 2. Use the machine on a flat and stable table in a ventilated room;
- 3. Wear heat-resistant gloves when using the machine;
- 4. Do not use the machine in a hazardous place;
- 5. Do not use the machine when it can't function properly;
- 6. Do not disassemble and reassemble the machine without special guidance;
- 7. Do not plug the machine in unsuitable AC outlet;
- 8. Do not touch the mug heater when the machine is heating up;
- 9. This machine is not intended for use by people (including children) who lack of physical or sensory capability, experience and knowledge, unless they have been given supervision and guidance by a person responsible for their safety;
- 10. Children should use the machine under the supervision of adults responsible for their safety;

PRODUCT INTRODUCTION



Note:

The mug heater is a vulnerable part, not covered by the warranty.




Note: Please make sure the voltage is compatible.

Connect the power cord to the inlet, and plug the mug press into AC socket.

Compatible Mug Size	11oz-15oz
Rated Power	280W
Rated Voltage / Frequency	220 V / 50 Hz
Rated Voltage / Frequency	110V / 60Hz


SWITCH ON/OFF



- 1. Press the switch button once to turn on the mug press.
- 2. Long press the switch button for 3 seconds to turn it off.

TEMP. SETTING


- 1. Turn off the machine or let it remain in off state:
- 2. Long press the button for 6 seconds;
- Release the button as the indicator light blinks in orange;
 The five lights above indicate different temp. levels. Press the button once to choose.
- 5. Wait for 5 seconds for the auto-save, and the machine exits the setting mode.
- 6. The initial temp. setting is 190°C.




COUNTDOWN SETTING

- 1. Turn off the machine or let it remain in off state;

- Long press the button for 10 seconds;
 Release the button as the indicator light blinks in green;
 The five lights above indicate different time lengths. Press the button once to choose.
- 5. Wait for 5 seconds for the auto-save, and the machine exits the setting mode.
- 6. The initial time. setting is 80 seconds.



HOW TO PRINT?









2. Put the mug into the mug heater. Once the sensor feels the mug, the mug heater start to close and wrap the mug automatically.

INDICATOR LIGHT STATE




If the first light is blinking in white, it indicates the machine is still heating up. The whole process takes about 180 seconds



If all lights are on, it indicates the whole printing process is finished. The mug heater will open automatically, and you can take out the mug.

EMERGENCY STOP



You can press the button anytime to open the mug heater in case of emergency.

RESET DISORDERED BLINKING LIGHT



Press the button for 5 times continuously to stop the machine. After 15 seconds, it will restart automatically.

PRINTING SETTING



Use sublimation printer to print your design on sublimation paper.



For 11oz Mug



For 15oz Mug



