

cricut autopress™

Get to know your Cricut Autopress



REAR VIEW



1 Handle

2 Indicator Lights
Orange = heating up
Green = ready to use
Red = machine
locked or Control
Pod disconnected

3 Heat Plate

CAUTION: Gets
very hot during use

4 Pressing Mat

5 Platen

6 Power Button

7 Lock/Unlock

8 USB Port


9 USB Cable

10 Power Port

11 Power Cord

12 Control Pod

Control Pod



13 Preset Buttons:

Press for 3 secs to
save settings

14 Temperature

15 Set Temperature:
Use dial to adjust

16 Timer:

Starts when
handle is pressed

17 Set Time:

Use dial to adjust

18 Micro-USB Port:

Connect machine
cable

19 C°/F° Toggle:

Switch from Celsius
to Fahrenheit

Use your heat press.

Before using for first time, activate Cricut Autopress at cricut.com/setup. Follow on-screen instructions to set up press and connect to Design Space®.

- Get time & temperature settings for your project at cricut.com/heatguide
- Position project on **Pressing Mat (4)**
- Use **Handle (1)** to lower heat plate
- Press handle to start timer

Note: Timer starts automatically

- Heat plate lifts automatically when complete
- Carefully remove project



CAUTION: Heat Plate (3) gets very hot during use. **Platen (5)** may become hot during use. Handle with care. Read safety instructions before use.